

Windows 7 and Vista Installation of Bixolon Display with Regit Express

There are varied methods for installing hardware between the different Windows versions and several paths that can be taken with each version. The instructions that come with the display are intended for Windows XP. Here is a method to install the driver if you cannot get the instructions that came with the device to work.

1. Download and extract the driver for your machine (64 or 32 bit) the 32 bit is also located on the included Bixolon CCD (also available on our web site at www.free-pos-software.com/drivers.htm). Pay attention to where you extracted the files, as you will need this location later.
2. Insert the BCD-1100 into a USB slot. A Windows message will say **Installing Device Driver Software**. It should not find your software.
3. Go to Windows button, then the Control Panel and open **Device Manager**.
4. Under **Other Devices**, right click **USB Serial Port**.
5. Click (left) the **Properties** selection on the drop down menu.
6. Click the **Update Driver** button near the bottom (Reinstall Driver on Vista).
7. Click **Browse my computer for driver software**.
8. Click the **Browse** button and browse to the extracted folder **BCD_win_v.1.0.5SE_x64 (or BCD_VirtualCOM for 32 bit)**.
9. Click/Check the **Include Subfolders** box.
10. Click **OK**, then **Next**.
11. Drive is not signed, click **Install the driver software anyway**.
12. The Driver installs.
13. **Close** the Install window.
14. Observe the COM number assigned to the USB Serial Port (COMx).
15. Close all opened screens including Device Manager.
16. Open Regit Express Office.
17. Click the customer display ICON (or Setup, External Customer Display).
18. Place the COM port number in the **Select COM Port Number** box.
19. Select the Bixolon BCD-1100.
20. Click OK/Save.
21. Return to the Cash Register.
22. Test by entering a product into a transaction.